



<b>Hazards</b>	
<b>Tools/Equipment</b>	syphon fed spray equipment, air supply
<b>Employee Group(s)</b>	Facilities Management - Carpentry

**Required PPE:**



**Ear  
Protection**



**Eye  
Protection**



**Solvent  
Resistant  
Gloves**



**Respirator**



**Safety  
Shoes**

**SAFE WORK PRACTICES**

- Do not perform the procedure or operate the equipment until you have been appropriately trained and authorized to do so by your supervisor.
- Inspect required personal protective equipment (PPE) and replace if required.

**PROCEDURE**

1. Clean booth – good housekeeping.
2. Check and bleed air compressor.
3. Check and maintain spray equipment.
4. Check manometer for efficient vacuum.
5. Turn on fans and lighting.
6. Perform checklist above (1 to 6).
7. After job completed:-
  - a. Turn off fans
  - b. Close fresh air intake
  - c. Shut off compressor
  - d. Clean spray gun.

---

*NOTE: All PPE, tools and equipment shall be used in accordance with provincial OH&S legislation, manufacturer's specifications, applicable standards and codes of practice.*